


Presentation Classroom Instructions

Holden Fine Arts Center 2125



- **Using the AMX Remote System**
- **Displaying a Blu-Ray through Projector**
- **Displaying a Video through Projector**
- **Displaying a DVD through Projector**
- **Displaying the Computer through Projector**
- **Displaying the Laptop through Projector**
- **Displaying the Document Camera through Projector**
- **Using the AMX to View Slides**
- **Listening to a Record**
- **Shut Down**


Holden Fine Arts Center 2125 Using the AMX Remote System

The Welcome Screen on the AMX



Press the “Touch here to start session” area to use the AMX system and turn on the projector. Any other equipment you plan to use needs to be manually turned on, by pressing the on/off buttons on the equipment.

The Main Menu Screen on the AMX




Select the equipment you want to use or make adjustments to:

- Computer/Doc Camera
- Blu Ray
- VCR
- DVD
- Volume
- Slides
- Turntable
- Projector & Screen

You may use “Shut Down System” option from this screen, which will shut down the AMX and turn off the projector. You need to manually turn off any other equipment you use.


Holden Fine Arts Center 2125 Using the AMX Remote System

The Blu-Ray Screen on the AMX



From this screen use play, stop, pause, fast forward, skip forward, rewind, and skip rewind to view the Blu-Ray disc. You can also open and close the disc tray from this screen.


The VCR Screen on the AMX



From this screen use play, stop, pause, fast forward, and rewind to view the movie. Other features you can control from this screen are the Channel Up and Channel Down (for use with cable television).

Holden Fine Arts Center 2125 Using the AMX Remote System

The DVD Screen on the AMX



From this screen use the DVD Menu button to access the DVD's menu. Use play, stop, pause, fast forward, rewind, skip fast forward, and skip rewind to view the DVD.

The Computer Screen on the AMX



From this screen you can select to use the Computer, a Laptop you have connected to the system, and the Document Camera. Once you have selected the device, you will need to manually control that piece of equipment.


Holden Fine Arts Center 2125 Using the AMX Remote System

The Slides Screen on the AMX



From this screen turn on the power to the slide projectors. Use the forward, reverse, focus in/out, and power off controls for Slide Projectors Left & Right.


The Turn Table Screen on the AMX



The message “Please operate the Turn Table manually!” will appear. You will need to manually control this piece of equipment.

Holden Fine Arts Center 2125 Using the AMX Remote System

The Volume Screen on the AMX



Turn the Volume up or down using this screen.

****Do not change the volume on the Amplifier, it has been set for this room****

To completely end your session, press the Shut Down System button. The AMX system and projector will turn off, but you will need to physically shut off the other equipment.

****Remember to reconnect the AMX Remote Control when you are finished****

Holden Fine Arts Center 2125 Displaying a Blu-Ray through Projector



1. Turn on the Blu-ray player, press the Open/Close button to open the disc tray and place the disc on the tray. Press the Open/Close button again to close disc tray.



2. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



3. Press Blu Ray on the Main Menu screen.



4. Use play, stop, pause, fast forward, rewind, skip fast forward, skip rewind and the DVD menu to view the movie.



Note: Pressing the Menu button on the right side will bring up the select menu.

Holden Fine Arts Center 2125 Displaying a Video through Projector




1. Turn on the VCR and put your VHS tape in.



2. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



3. Press VCR on the Main Menu screen.



4. Use play, stop, pause, fast forward, and rewind on the AMX screen to view the movie.

Holden Fine Arts Center 2125 Displaying a DVD through Projector



1. Turn on the DVD player, press the Open/Close button to open the disc tray and place the DVD disc on the disc tray. Press the Open/Close button again to close disc tray.



2. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



3. Press DVD on the Main Menu screen.



4. Use play, stop, pause, fast forward, rewind, skip fast forward, skip rewind and the DVD menu to view the movie.



Note: Pressing the Menu button on the right side will bring up the select menu.

Holden Fine Arts Center 2125 Displaying the Computers through Projector




1. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



2. Press Computer on the Main Menu screen.



3. Select the computer icon on the screen and use the computer as you normally would.



4. The computer is a dual boot iMac, it has both a Mac and Windows operating system on it. To select the operating system you would like to use:

- Turn on the computer (located on the back in lower left corner) while holding down the “Options” button on the keyboard.
- Select the PC or Mac icons on the screen and log in as you normally would.



Holden Fine Arts Center 2125 Displaying the Laptop through Projector




1. Connect the Laptop to the cables on the equipment desk.

2. Turn on the Laptop.



3. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.




4. Press Computer on the Main Menu screen.



5. Select the laptop icon on the screen and wait for AMX to connect to the laptop. The laptop is not controlled from the AMX system, but should project to the screen.

Holden Fine Arts Center 2125 Displaying the Document Camera through Projector




1. Turn on the Document Camera.

2. Place the materials to display on the Document Camera and use the zoom in and out controls as needed.



3. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



4. Press Computer on the Main Menu screen.



5. Select the Doc Cam image on the screen and wait for AMX to connect to the document camera. The doc cam is not controlled from the AMX system, but should project to the screen.

Holden Fine Arts Center 2125 Using the AMX to View Slides



1. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



2. Press Slides on the Main Menu screen.



3. Using the AMX Remote System, turn on the Slide Projectors.



4. Use the forward, reverse, and focus buttons for both projectors.



5. When finished with viewing slides, turn off the power to both slide projectors.

Holden Fine Arts Center 2125

Listening to a Record on the Turn Table



1. Press the “Touch here to start session” area on the AMX Remote System. The projector will turn on.



2. Press Turntable on the Main Menu screen.



3. At this screen, pull out the turntable and place your record on the player. Use the controls on the player to listen to your record.



Holden Fine Arts Center 2125 Shut Down

1. Log off the computer like you normal would.
2. Turn off the Blu-Ray Player.
3. Turn off the DVD/VCR.
4. Turn off the Slide Projectors.
5. Turn off the Turntable.
6. Press the Shut Down System button, which will shut down the AMX and turn off the projector.
7. Reconnect the AMX Remote Control for charging.